THE CHIMNEY NOBODY CHECKS

A Homeowner's Guide to Chimney Fires, Carbon Monoxide, and Hiring a Sweep Who Won't Rip You Off

EDEN AMIR

Founder, E Cleaning Duct & Vent Cleaning

Copyright © 2026 by Eden Amir / E Cleaning LLC. All rights reserved.

No part of this book may be reproduced in any form without written permission from the author, except for brief quotations in reviews.

Disclaimer: This book is for general informational purposes only. It is not a substitute for professional inspection, manufacturer instructions, or local building codes. Fireplaces, flues, roofs, ladders, and combustion appliances carry real risk, including fire and carbon monoxide hazards. If you are not comfortable or qualified to perform any task described here, hire a qualified professional. The author and publisher assume no liability for damages or injury resulting from the use of the information in this book. Fire and safety statistics cited are drawn from publicly available materials by the National Fire Protection Association (NFPA), the Chimney Safety Institute of America (CSIA), the CDC, and the EPA.

All photographs in this book are real, unretouched photos taken on actual service calls in southeastern Pennsylvania. Diagrams and cutaway illustrations are original artwork created for this book.

First edition. Printed in the United States of America.

ecleaning-duct-vent-cleaning.com

Contents

Introduction: The Fire That Already Happened

1. The Fire You Never Hear

2. How a Chimney Actually Works

3. Creosote: The Three Stages, and Why Stage Three Changes Everything

4. Carbon Monoxide: Your Chimney Is Not Just for Fireplaces

5. The Warning Signs of a Chimney in Trouble

6. Water: The Slow Killer of Every Masonry Chimney

7. Animals, Nests, and the Things We Pull Out of Flues

8. The Annual Inspection: NFPA 211 and the Three Levels

9. The Bait-and-Switch Playbook — and How to Hire a Sweep Who Won't Rip You Off

10. Burn Better: The Habits That Starve Creosote, and Your Year-Round Chimney Plan

Appendix A: Chimney Maintenance Log

Appendix B: Hiring Checklist — What a Real Sweep and Inspection Includes

Glossary

About the Author

INTRODUCTION

The Fire That Already Happened

A few years into running my cleaning company, I put a camera up a flue in a handsome stone colonial and watched the screen fill with something the homeowner had never seen: cracked clay tiles, wide-open mortar joints, and a black glaze over everything, blistered and bubbled like burnt sugar.

"When was your chimney fire?" I asked.

She laughed. "We've never had a chimney fire."

She had. The evidence was six feet above her damper — thermal cracks that only extreme heat produces, and creosote that had clearly ignited, expanded, and gone out on its own, probably while the family sat in front of the fireplace enjoying the evening. Nobody heard it. Nobody smelled it. The house survived because the fire ran out of oxygen or fuel before it found the framing sitting on the other side of those cracked tiles. The next one might not be so polite.

That job changed how I talk to customers, and it is why this book exists. Here is the uncomfortable truth of my trade: a large share of chimney fires are never noticed by the people whose house is burning. They are slow, oxygen-starved fires inside a masonry tube, and the first anyone learns of them is when someone like me sends a camera up — or when the second fire finishes what the first one started.

I'm Eden Amir. I founded E Cleaning Duct & Vent Cleaning in King of Prussia, Pennsylvania, and over thousands of homes across Chester, Montgomery, Bucks, Berks, Delaware, and Philadelphia counties, my crews have swept, scoped, and repaired just about every kind of chimney southeastern Pennsylvania builds. If you read my earlier book about dryer vents, *The Hidden Fire in Your Laundry Room*, you know my

style: no fluff, no scare tactics, real numbers, and the honest version of how my own industry works — including the parts that should embarrass it.

Because chimney service has a dark side, and I am going to show it to you. This is the industry of the $69 sweep special that turns into a $12,000 on-the-spot reline quote. Of "technicians" who diagnose a catastrophic chimney with a flashlight and a frightened homeowner. I will hand you the entire bait-and-switch playbook in Chapter 9, and once you've read it, it will never work on you again.

But first you need to understand the thing itself. In the next ten short chapters you will learn how a chimney actually moves smoke, what creosote is and why its third stage is a different animal from the first two, how carbon monoxide sneaks out of the flues nobody thinks about — the ones serving your furnace and water heater — what the national inspection standard actually requires, what the warning signs look like, what water does to brick, and how to burn wood in a way that starves the whole problem at its source.

You can read this book in about an hour. It may be the highest-return hour your house ever gets from you.

Let's start with the fire — the one that roars, and the one that doesn't.

CHAPTER ONE

The Fire You Never Hear

The Chimney Safety Institute of America estimates that there are roughly 25,000 chimney fires in the United States every year, causing more than $125 million in property damage. And the National Fire Protection Association's numbers frame the bigger picture: heating equipment is one of the leading causes of home fires in this country — U.S. fire departments have responded to an average of roughly 48,000 heating-equipment fires per year, killing about 500 people annually — and the single leading factor in those fires, cited in about a quarter of them, is *failure to clean*, principally chimneys.

Read that the way I do: the number-one contributing factor in home heating fires is not defective stoves or faulty furnaces. It is soot and creosote that nobody removed.

The Two Kinds of Chimney Fire

Chimney fires come in two personalities, and most homeowners only know about one of them.

The dramatic one. This is the fire from the news. It sounds — and I have heard homeowners use these exact words independently, for decades — "like a freight train" or "like a jet engine." Flames or dense smoke shoot from the top of the chimney. The roar comes from a huge volume of air being sucked violently up the flue to feed the burn. Neighbors call 911 before the homeowners even know. These fires can reach 2,000 degrees Fahrenheit or more — hot enough to crack clay flue tiles, damage metal liners, and push flame through masonry gaps into the wood framing of the house.

The quiet one. This is the fire from my camera screen. It is slow-burning and starved for air, so there is no roar and often no visible sign at all from inside the living room. It smolders in the creosote layer, reaches temperatures high enough to damage the

flue, and goes out. The homeowners never know. Fire-safety organizations have long warned that a large share of chimney fires go undetected — the evidence turns up later, during inspections, as cracked tiles, "puffy" expanded creosote, and warped dampers.

Here is why the quiet ones scare me more than the loud ones. A chimney is designed to contain the byproducts of a controlled fire — a few hundred degrees of smoke. It is not designed to survive a 2,000-degree burn inside its own walls. Every chimney fire, loud or silent, damages the flue's ability to do its one job: keeping heat and combustion gases away from the structure of your house. Which means the most dangerous chimney fire is usually the *second* one — the one that finds the cracks the first one made.

Where the Fuel Comes From

A chimney fire needs fuel, and the fuel is creosote — a black or brown residue that condenses out of wood smoke onto the inside of the flue. Every wood fire deposits some. Cool flues, smoldering fires, and wet wood deposit a lot. Creosote is not soot; it is a concentrated, tar-like fuel, and in its worst form it is glossy, hardened, and packed with enough energy that a single stray spark or one very hot fire can ignite the whole column. Chapter 3 is devoted entirely to it, because understanding creosote's three stages is the difference between a chimney that gets maintained and a chimney that gets rebuilt.

The Season That Concentrates the Risk

Home heating fires cluster hard in December, January, and February — the months when fireplaces and stoves run daily, when flues stay cold and condense more creosote, and when a year's worth of buildup meets the hottest, longest fires of the season. In my service area, the phone calls follow the same curve: the first cold snap of fall lights ten thousand first-fires-of-the-year in flues nobody has looked at since spring.

The entire chimney fire problem has one honest summary, and it fits in a sentence from the fire data itself: these fires overwhelmingly happen in chimneys that were not cleaned and not inspected. Which makes this one of the most preventable serious hazards in your entire house.

If It Happens: The Four-Minute Script

I hope you never need this paragraph, but it belongs in Chapter 1, not buried in an appendix. If you ever hear that roar, see flames or heavy sparks at the chimney top, or smell intense burning with a rumbling or ticking from the chimney wall, here is the script:

1. **Get everyone out and call 911 from outside.** Even if the fire seems to die down, the flue may already be breached and fire may be inside the wall cavities where you can't see it. Firefighters have thermal cameras; you don't.
2. **If — and only if — you can do it safely on your way out**, cut the fire's air: close the fireplace's glass doors, or shut the air inlets on a wood stove. A chimney fire is an air-hungry event, and starving it slows it.
3. **Do not pour water into the firebox or flue.** Water flashing to steam inside a 2,000-degree clay tube can crack the entire liner explosively and does the fire little harm.
4. **After the fire department leaves, the flue is out of service** until a Level 2 inspection (Chapter 8) with a camera confirms — or rules out — liner damage. Every chimney fire, even a "small" one, is an automatic inspection trigger under the national standard. Insurance generally treats a documented chimney fire as a covered sudden event; the camera report is your evidence.

Four minutes of knowing what to do, versus the most common improvisations — garden hoses into flues, waiting to "see if it stops," relighting the next weekend — is a large part of why identical fires end so differently in different houses.

THE ONE-SENTENCE TAKEAWAY

Tens of thousands of chimney fires happen every year, many burn silently without the homeowner ever knowing, and the leading cause is the same in almost every case — a flue nobody cleaned.

CHAPTER TWO

How a Chimney Actually Works

Nobody can maintain — or push back on a dishonest quote about — equipment they can't picture in their head. So let's build a chimney from the fire up, naming every part, because these are the exact words that will appear on your inspection reports and repair estimates. When a sweep tells you your crown is shot or your smoke chamber needs parging, you should know precisely what he means and roughly what it's worth.

The Draft: Why Smoke Goes Up at All

A chimney is not a passive pipe. It is an engine. Hot gas is lighter than cold air, so the column of hot smoke inside the flue rises, and as it rises it pulls fresh air into the fire below. That pull is called **draft**, and everything about chimney design serves it. Taller chimneys pull harder. Warmer flues pull harder. An interior chimney, kept warm by the house around it, drafts better than a chimney slapped on an exterior wall in January.

Draft is also fragile. A cold exterior flue, a too-tight modern house starving the fire of makeup air, a kitchen exhaust fan running at the wrong moment, a flue that's too big or too small for the appliance feeding it — any of these can weaken or reverse the draft. When draft fails, smoke backs into the room. Worse, in the flues you'll meet in Chapter 4, when draft fails, carbon monoxide backs into the house.

The Anatomy, Bottom to Top



The parts of a chimney I check on every visit — most of them you will never see from your living room.

The firebox is where the fire lives — built of heat-resistant firebrick in a masonry fireplace, or a metal box in a factory-built unit.

The damper is the metal plate above the firebox that you open to burn and close to keep your heated house air from pouring up the chimney the other 8,000 hours a year. Most are throat dampers, rusting quietly in the dark; a top-sealing damper mounted at the chimney's crown is the modern upgrade.

The smoke chamber is the sloped funnel between the damper and the flue — and it is the part of the chimney most homeowners have never heard of, which is a shame, because it takes tremendous abuse. Turbulent smoke swirls here and deposits creosote heavily. In many older homes the smoke chamber's walls are stepped, rough, corbeled brick — full of ledges that catch creosote. The fix, called **parging**, smooths those walls with a refractory coating. It is a real, legitimate repair — and also, as you'll see in Chapter 9, one of the industry's favorite things to sell whether you need it or not.

The flue liner is the inner tube that actually carries the smoke — historically clay tiles stacked and mortared, in newer or relined systems a stainless steel pipe, or a poured cement liner. The liner is the whole ballgame. It contains heat, it contains gases, and it protects the masonry from corrosive combustion byproducts. Older homes — plenty of them in my counties, built before liners were standard — sometimes have no liner at all, just bare brick, which is exactly as bad as it sounds.

The chimney itself — the brick or stone you see — is the structure that holds the liner and carries everything above the roof. One masonry chimney frequently contains *multiple* flues: one for the fireplace, another for the furnace and water heater. Remember that; it becomes the entire point of Chapter 4.

The crown is the cement slab on top, sloped to shed water away from the flue openings. It is the chimney's roof, and when it cracks, water gets into everything below it.

The cap is the metal lid-and-screen assembly over each flue opening. It keeps out rain, animals, and debris while letting smoke pass. It costs less than a nice dinner out, and I would

estimate half the chimneys I meet for the first time don't have one.

The flashing is the sheet-metal skirt sealing the joint where the chimney passes through the roof — one of the most common leak points on any house.

Inserts, Stoves, and Gas Logs: Same Chimney, Different Rules

Not every fire in a masonry chimney is an open fireplace, and the variations matter enough to name here.

A **wood-burning insert** is a metal stove slid into a fireplace opening. Done right, it dramatically improves heat output — and it *must* be installed with a full stainless liner connecting the insert's collar to the chimney top. The shortcut version — the insert simply shoved into the opening, dumping smoke into the huge old flue (a "slammer," in trade slang) — cools the smoke instantly and glazes chimneys faster than almost anything else I see. If you have an insert and don't know whether it's fully lined, that question belongs in your next inspection.

A **freestanding wood stove** connected into a masonry chimney concentrates its smoke into a small, controllable firebox — which is exactly why stove flues, damped down overnight, are the stage-three champions of Chapter 3. Stove owners: your maintenance tempo is faster than a fireplace owner's, not slower.

Gas logs and gas fireplaces produce no creosote — and this is where homeowners relax one notch too far. Gas combustion still produces water vapor, corrosive condensate, and carbon monoxide; gas flues still get blocked by nests and shed tile; and vent-free gas logs (where legal at all) put every combustion byproduct directly into your room air by design. "It's just gas" has preceded a remarkable number of the CO incidents in Chapter 4. The annual inspection requirement does not have a gas exemption.

Why Size and Match Matter

A flue must be matched to its appliance. Too small and it can't carry the volume; too large and the smoke rises slowly, cools, and condenses — more creosote in a wood flue, more corrosive moisture in a gas flue. This mismatch is not an exotic problem. It happens in real houses every time someone installs a new high-efficiency furnace or a fireplace insert and leaves the old oversized flue unchanged. It is one of the legitimate reasons a professional will recommend a properly sized liner — and one more thing you'll be equipped to evaluate rather than take on faith.

THE ONE-SENTENCE TAKEAWAY

A chimney is a draft engine built from firebox, damper, smoke chamber, liner, crown, cap, and flashing — learn those seven words and no inspection report or repair quote will ever be a mystery to you again.

CHAPTER THREE

Creosote: The Three Stages, and Why Stage Three Changes Everything

If this book gets one chapter tattooed on your memory, make it this one. Creosote is the fuel of nearly every chimney fire, and it does not arrive all at once — it arrives in three escalating stages. Knowing which stage is in your flue tells you whether you need a $200 sweep, a specialized treatment, or a serious conversation. It is also your armor: the bait-and-switch artists of Chapter 9 love to describe every chimney as a stage-three emergency, and after this chapter you'll know what questions expose that.

Where Creosote Comes From

Wood never burns completely. Smoke carries unburned gases, tar droplets, and water vapor up the flue, and wherever that smoke cools below roughly 250 degrees Fahrenheit — which happens against the walls of every flue, especially cold exterior ones — those compounds condense onto the surface. That condensate is creosote. The formula for producing a lot of it is simple: cool flue plus slow, smoky, oxygen-starved fire plus wet wood. The formula for producing very little is the mirror image, and it is the whole of Chapter 10.

Stage One: Soot and Flake

First-degree creosote is mostly a soft, sooty, flaky dust with high soot content. It comes from reasonably hot fires with decent airflow. It brushes off the flue walls easily — this is exactly what a standard chimney sweeping removes, with rods and a properly sized brush. If you burn dry wood, hot, in a well-drafting flue, stage one is most of what you'll ever produce, and an annual sweep keeps you permanently in this zone. Stage one is a maintenance item, not a hazard headline.

Stage Two: Hardened Tar Flakes

Second-degree creosote looks like shiny black cornflakes — hardened, crunchy tar flakes with less soot and more concentrated fuel. It typically comes from restricted-air burning: glass-doored fireplaces run with the doors shut, wood stoves damped down overnight, slow smoldering fires. Stage two doesn't surrender to a basic brush pass; removing it takes stiffer brushes and more aggressive mechanical work. It is removable, but it marks a flue that is being burned wrong, cooled too much, or both — a flue on its way to stage three.

Stage Three: The Glaze

Third-degree creosote is a different substance in every way that matters. It forms when creosote condenses faster than it can dry — layer after layer flowing, baking, and re-melting into a hardened glossy **glaze** on the flue wall, sometimes thick, sometimes dripping into hardened runs like black candle wax. It is essentially concentrated fuel varnished onto the inside of your chimney. It cannot be brushed off; a brush skates over it. Removing it takes special rotary equipment with chains or cutters, or chemical treatments that break the glaze down over multiple applications so it can finally be extracted.

And this is the stage that burns. When a chimney fire ignites a glazed flue, there is a deep bed of dense fuel to feed it — this is where the freight-train fires and the tile-cracking temperatures come from. Stage three glaze is also the residue that puffs up into porous, honeycombed, expanded creosote after a fire — the signature my camera finds in flues whose owners "never had a chimney fire."



The three stages of creosote. Stage one brushes away; stage three is varnished-on fuel that takes special equipment to remove — and it is the stage that burns.

How Fast Does It Build?

There is no universal answer, because the inputs vary so much — but the ranges are instructive. A fireplace burning dry hardwood a few evenings a week, hot and open, may deposit only a light stage-one coat in a whole season. The same fireplace burning wet wood behind closed glass doors can lay down dangerous accumulation in a *single* season. Wood stoves damped down overnight, every night, are the fastest builders I see — some glaze in one winter. The old rule of thumb in the trade is that buildup of about an eighth of an inch of soot — sooner if any glaze is present — means the flue is due for sweeping regardless of the calendar. This is exactly why the standard requires annual *inspection* rather than blind scheduled sweeping: the inspection tells you which chimney you are.

One more myth to retire while we're here: the "creosote sweeping log" you've seen at the hardware store. Those chemical logs can

modify creosote and make some deposits more brittle, and CSIA acknowledges they may help *as a supplement* — but they do not remove anything from the flue, they cannot address stage three glaze, and they are not a substitute for mechanical sweeping or for the annual inspection. A flue "maintained" by fireplace logs alone is an unswept flue with better marketing.

The Honest Translation Table

Here is how the three stages should translate into what you're told and what you pay:

- **Stage one:** routine sweeping. Standard price. Anyone competent can do it.
- **Stage two:** heavier mechanical cleaning. Modestly higher price, honestly explained.
- **Stage three:** specialized removal — rotary cleaning or chemical treatment, sometimes over more than one visit — plus a real conversation about *why* your flue is glazing: wet wood, smoldering burns, an oversized or exterior cold flue. Fixing the cause matters as much as removing the glaze.

Notice what's *not* on that list: "your chimney is a stage-three death trap and needs a $10,000 reline today, decide now." Stage three creosote is serious. It is also diagnosable on camera, documentable in photos, and addressable in defined steps. Any professional who can't show it to you doesn't get to charge you for it.

THE ONE-SENTENCE TAKEAWAY

Creosote escalates from brushable soot to tar flakes to a glazed, brush-proof fuel varnish — stage three is the one that feeds violent chimney fires, and any company claiming you have it should be able to show it to you on camera.

CHAPTER FOUR

Carbon Monoxide: Your Chimney Is Not Just for Fireplaces

Ask a homeowner what their chimney is for and they'll point at the fireplace. Then I walk them to the basement and point at the metal pipe running from their furnace — and another from their water heater — into the side of that same masonry chimney. For millions of American homes, the chimney's most important job has nothing to do with firewood. It is the exhaust system for the appliances that run every single day. And when that exhaust path fails, the result is not smoke in the living room. It is carbon monoxide in the bedrooms.

The Gas That Gives No Warning

Carbon monoxide is the byproduct of incomplete combustion — from gas, oil, wood, any fuel. It is colorless, odorless, and tasteless. The CDC reports that at least 400 Americans die every year from accidental, non-fire-related CO poisoning, and more than 100,000 end up in emergency rooms. The early symptoms — headache, dizziness, nausea, fatigue — are so ordinary that families routinely treat a CO exposure as "we're all coming down with something." The tell that too many people learn about afterward: everyone feels better when they leave the house.

I am not telling you this to frighten you. I am telling you because the chimney-related causes of CO backup are specific, physical, findable things — and every one of them shows up on a proper inspection.

How a Chimney Turns Against You



A chimney is not just for fireplaces. Your furnace and water heater often vent through it too — and a blockage there is how carbon monoxide backs up into the house.

Blockage. A flue blocked by a bird nest, a dead animal, leaves, or collapsed tile debris cannot vent. The exhaust has to go somewhere, and "somewhere" is back down the pipe and into the

house. I have pulled nests the size of basketballs out of furnace flues that were, at that moment, serving a running appliance.

Deterioration. Combustion exhaust — especially from modern gas appliances — is wet and acidic. Inside an old, unlined or clay-lined masonry chimney, that moisture condenses and eats mortar joints and tile from the inside, decade after decade. Eventually the flue shells debris into itself and chokes, or opens gaps that leak exhaust into the house's walls. From the outside, the chimney looks fine.

Orphaned flues. Here is the scenario almost nobody has heard of, and it is common in my service area. A homeowner upgrades to a high-efficiency furnace, which vents through a plastic pipe out the side wall. The old masonry chimney now serves only the water heater — a small appliance sending a whisper of warm exhaust up a huge, cold flue built for a much bigger load. The exhaust cools, stalls, and condenses instead of rising. The industry calls that water heater an **orphan**, and the standard fix is a correctly sized metal liner. If you've replaced a furnace in the last decade and nobody discussed your water heater flue, put this book down and go look at what that water heater vents into.

Failed draft. Tight modern houses, powerful kitchen and bath exhaust fans, and competing appliances can depressurize a home enough to stall or reverse a natural-draft flue. The appliance runs; the exhaust drifts backward into the room.

Your Three-Layer Defense

Layer one: CO alarms. On every level of the home and near every sleeping area, per CDC and NFPA guidance. Test them monthly; replace per the manufacturer's date. Alarms are the last line of defense, not the first — by the time one sounds, CO is already in your air. If a CO alarm ever goes off, get everyone out and call 911. Do not open windows and "wait to see if it stops."

Layer two: annual inspection of every flue. Not just the fireplace flue. The national standard you'll meet in Chapter 8,

NFPA 211, covers *chimneys and vents* — the furnace and water heater flues included. When you book a chimney inspection, say the words: "I want the heating appliance flue checked too."

Layer three: caps and liners. A capped flue can't fill with nests and leaves. A properly sized liner gives acidic exhaust a corrosion-resistant, correctly proportioned path that stays warm enough to draft. These are the two highest-value CO-prevention upgrades in the entire chimney world.

THE ONE-SENTENCE TAKEAWAY

The deadliest chimney failures involve no fire at all — blocked or crumbling furnace and water-heater flues push odorless carbon monoxide back into the house, which is why every flue in the chimney gets inspected annually and every bedroom hallway gets a CO alarm.

CHAPTER FIVE

The Warning Signs of a Chimney in Trouble

Chimneys do send distress signals. The trouble is that each one is easy to explain away in the moment — "the wind must be weird today," "old houses smell like that," "a little rust is normal." Here is the list I check against on every first visit. One sign alone earns attention; two or more means the system needs a professional look before the next fire is lit.

Smoke Backing Into the Room

A healthy fireplace takes its smoke upstairs immediately. Smoke rolling out from under the mantel means the draft is failing, and draft fails for findable reasons: a blocked or partially blocked flue, a closed or rust-frozen damper, a cold flue that never established flow, a flue too small for the opening, or a house too tight to supply combustion air. An occasional puff on a windy day is one thing. Regular smoke spillage is a diagnosis waiting to be read.

The Smell

A strong campfire or asphalt odor from the fireplace — worst on humid summer days and rainy stretches — is the smell of creosote. Humid air moving down the flue carries its scent into the house, and the stronger the smell, the heavier the deposit. Bonus signal: a smelly chimney in summer usually also means air is flowing *down* the flue, which is its own draft red flag. Deodorizers treat the symptom. Sweeping treats the cause.

Rust Where Rust Shouldn't Be

A rusted damper that grinds, flakes, or won't seat is more than an annoyance — rust means moisture, and moisture in the firebox means water is getting into the chimney somewhere above. Same

for rust streaks on a metal cap or chase cover, or rust stains on the firebox floor. Follow the rust upstream and you almost always find a failed crown, cap, or flashing — which is the whole of Chapter 6.

Spalling Brick

Spalling is when the faces of bricks flake, peel, or pop off, leaving crumbly craters and a telltale confetti of brick shards on the roof or ground around the chimney. It means water has soaked into the masonry and frozen, breaking the brick apart from within. Find brick flakes at the base of your chimney and you have found a structural process in progress — one that only accelerates.

Stains, Wallpaper, and White Fuzz

Dark staining on the ceiling or walls around the chimney chase, damp patches after rain, peeling paint or wallpaper near the chimney breast — water. A white, fluffy deposit on exterior brick, called **efflorescence**, is minerals left behind by water evaporating *through* the masonry; it wipes off, but it is a written confession that the chimney is absorbing water. And any dark, oily staining bleeding through around the chimney can be creosote-laden moisture — a sign worth a same-week call.

Pieces in the Firebox

Open the damper and look up with a flashlight. Chunks of tile, curls of what looks like burnt black cereal (that's expanded creosote — evidence of a past fire), gritty mortar debris, twigs, or feathers on the smoke shelf all mean the flue is shedding into itself or something is living in it. A flue should not deliver anything to the firebox except smoke going the other way.

The Ten-Minute Self-Check You Can Do Tonight

None of this requires a ladder. Grab a strong flashlight and do the following, in order:

1. **Outside, from the ground:** binoculars on the chimney top. Is there a cap on every flue? Is the crown visibly cracked or is anything leaning, gapped, or missing? Any brick shards on the roof or in the flower bed below?
2. **The flashing line:** any tar smears, lifted metal, or staining on the roof around the chimney base?
3. **Inside, at the fireplace:** open the damper — does it move freely, seat firmly, and come back without a fight? Rust flakes raining down as you do it are a data point.
4. **The flashlight look-up:** with the damper open, look up the flue. You're not diagnosing — you're just noting: daylight or a cap silhouette at the top (good), heavy black texture on the walls, debris on the smoke shelf, or anything obviously hanging (all worth a call).
5. **The sniff test:** nose into the firebox. Mild woodsmoke is normal in a burning-season house. Strong tar, or anything animal, is not.
6. **The paper trail:** find your last inspection report. Can't find one? That's finding number one.

Ten minutes, and you'll walk away knowing whether you're calling for a routine annual visit or describing specific symptoms — which, incidentally, is exactly the kind of customer the bait-and-switch companies of Chapter 9 quietly hope they never get.

The Meta-Sign: Time

If you cannot name the year of your last chimney inspection, that is itself the finding. Every standard, every fire-safety authority, and every honest sweep says the same thing: once a year, every year, burning season or not. Chapter 8 explains exactly what that

inspection should include so you can tell a real one from a drive-by.

THE ONE-SENTENCE TAKEAWAY

Smoke spillage, campfire odor in summer, rust, spalling brick, stains, and debris in the firebox are the chimney's six distress signals — one means pay attention, two or more means stop burning and get it inspected.

CHAPTER SIX

Water: The Slow Killer of Every Masonry Chimney

Fire gets the headlines, but water pays my repair crews. Ask anyone in this trade what actually destroys chimneys in the northeastern United States and the answer is unanimous: water, working with winter. A chimney is the most exposed structure on your house — hit by rain from every direction, soaked, frozen, thawed, and refrozen dozens of times each winter — and unlike your siding and roof, it is built from materials that drink.

Freeze-Thaw: The Demolition Cycle

Brick and mortar are porous. Water soaks in, and when it freezes it expands about 9 percent — inside the pores of the masonry. Each freeze pops the structure apart microscopically; each thaw lets more water in deeper. In a Pennsylvania winter, a single wet week can run that cycle many times. Multiply by years and you get spalled brick faces, crumbling mortar joints, loose crowns, and eventually a chimney that leans or sheds bricks. Water damage is never static. Every season it is either being stopped or getting worse.



The four places water gets into a masonry chimney. A cracked crown or missing cap lets the freeze-thaw cycle take the whole structure apart from the inside.

The Crown: The $300 Slab Protecting the $15,000 Chimney

The crown is the sloped cement cap sealing the top of the chimney around the flue tiles. It takes the worst weather exposure of any surface on your house, and on many homes it was built wrong to begin with — a thin slick of mortar rather than a proper overhanging concrete slab. When the crown cracks, water pours into the top of the chimney's core and the freeze-thaw demolition begins from the inside.

Crown repair is honest, valuable work: small cracks get a flexible crown sealant; failed crowns get rebuilt with proper cast concrete and a drip edge. It is also a favorite upsell precisely because you can't see your crown from the ground — which is why, in Chapter 9, the rule will be: photos or it didn't happen.

The Cap: The Cheapest Insurance in This Book

An uncapped flue is an open hole in your roof, funneling rain and snowmelt all year long down a shaft that runs through the middle of your house. That water rusts the damper, soaks the smoke shelf into a creosote soup (there's your summer smell), erodes tile mortar joints, and feeds mold in adjacent framing. A quality stainless steel cap with an animal screen typically costs less than a family dinner out, installs in minutes, and blocks rain, birds, raccoons, and debris simultaneously. One caution, and it applies to every "quick" chimney-top job in this book: the cap is cheap, but the trip to it is not — it lives on your roof, and ladder and roof falls send far more homeowners to the emergency room every year than chimney fires do. Unless you are properly equipped and genuinely comfortable with ladder and roof work, have the cap installed during your sweep's next visit; they're up there anyway. If your chimney has no caps, that is the first dollar you should spend after reading this book.

Flashing: Where the Roof Meets the Problem

Flashing — the layered sheet metal sealing the chimney-to-roof joint — is among the most common leak sources on any home, and its leaks are habitual liars: water follows rafters and shows up as a ceiling stain six feet from the chimney, so the roofer gets called and the chimney gets blamed for nothing. Properly done flashing is two-part (step flashing woven into the shingles, counter-flashing cut into the masonry). Tar smeared into the joint is not flashing; it is a countdown timer.

Waterproofing That Actually Works

After repairs, masonry can be treated with a vapor-permeable water repellent — a formulation that keeps liquid water out while letting the brick breathe moisture outward. That last property matters: sealing brick with a non-breathable film traps moisture inside and *accelerates* freeze-thaw spalling. If a company

proposes "sealing" your chimney, the only acceptable answer to "is it vapor-permeable?" is yes.

The Order of Operations

Water problems compound, so fix them top-down and outside-in: crown first, then cap, then flashing, then repointing (regrinding and refilling failed mortar joints), then breathable water repellent. A homeowner who spends a few hundred dollars at the right layer this year routinely avoids a four- or five-figure rebuild five years out. I have watched both timelines play out more times than I can count.

THE ONE-SENTENCE TAKEAWAY

Water plus freeze-thaw is what actually destroys chimneys — a sound crown, a cap on every flue, real two-part flashing, and breathable water repellent cost hundreds and prevent the rebuilds that cost thousands.

CHAPTER SEVEN

Animals, Nests, and the Things We Pull Out of Flues

From an animal's point of view, an uncapped chimney is the best real estate in the neighborhood: elevated, sheltered, predator-proof, and warm. From my point of view, animals are one of the most common causes of the blocked flues behind Chapter 4's carbon monoxide problem. This is a short chapter with an outsized payoff, because the fix is cheap and permanent.

The Regulars

Birds. The champion is the chimney swift — a small, cigar-shaped bird that nests on vertical surfaces and loves flues. Here is what surprises homeowners: chimney swifts are federally protected under the Migratory Bird Treaty Act. Once an active nest with eggs or young is in your flue, it cannot legally be removed until the birds leave at the end of the season. You wait, then sweep, then cap. The swifts are actually good houseguests as squatters go — but their nests are flammable, and other birds (starlings, sparrows) build bulky flammable nests with no legal protection and no manners.

Raccoons. Female raccoons treat smoke shelves as maternity wards every spring. A raccoon in your flue can carry rabies and parasites and will defend her kits. This is a wildlife-professional situation, not a broom situation.

Squirrels. Usually falls rather than tenants — a squirrel that slips down a flue often can't climb back out of slick tile, and panicked wildlife in a firebox is memorable for everyone involved.

And the rest. Bats, snakes investigating bird nests, bees and wasps, and — the saddest and most common finds — animals

that fell and didn't survive, announcing themselves by odor and flies weeks later.

Why This Is a Safety Chapter, Not a Nuisance Chapter

A nest in a fireplace flue is kindling positioned directly in the path of sparks. A nest in a furnace or water-heater flue is a carbon monoxide dam. Nesting debris also holds moisture against tile and mortar, accelerating the water damage of Chapter 6. And nests come with passengers — mites, fleas, droppings, and histoplasmosis-associated material in bird and bat accumulations — that you do not want raining into your firebox. Sudden signs of animal presence mid-season — scratching, chirping at dawn, odor, debris on the smoke shelf — mean stop using the appliance that flue serves until it's cleared.

The Fix Is a Cap — the Right Cap

Every flue gets a cap with an animal screen. Stainless steel, sized to the flue, mechanically fastened. Two cautions. First, on flues serving gas or oil appliances, the cap must be appropriate to the venting system — screens on appliance flues must not be so fine that they clog with exhaust condensation frost in winter, which recreates the blockage you were preventing. Second, timing: cap *after* confirming the flue is empty and unoccupied — capping an animal inside is a cruelty and a guaranteed dead-animal blockage. A sweep with a camera confirms empty, cleans, and caps in one visit.

THE ONE-SENTENCE TAKEAWAY

Animals turn open flues into fire kindling and carbon monoxide dams — and the permanent fix is a screened stainless cap on every flue, installed right after a camera confirms nobody's home in there.

CHAPTER EIGHT

The Annual Inspection: NFPA 211 and the Three Levels

There is an actual national standard for chimney care, and knowing its name changes every conversation you'll ever have with a chimney company. It is **NFPA 211: Standard for Chimneys, Fireplaces, Vents, and Solid Fuel-Burning Appliances**, published by the National Fire Protection Association, and its core requirement is one sentence long: chimneys, fireplaces, and vents shall be inspected at least once a year. Not "when something seems wrong." Not "every few years if you burn a lot." Annually — even if you didn't burn at all, because Chapter 6's water damage and Chapter 7's animals don't care whether you lit fires.

NFPA 211 defines three levels of inspection. Learn them, because "which level are you performing, and what does it include?" is the single most professional-sounding question a homeowner can ask — and the response tells you instantly who you're dealing with.

Level 1: The Annual Routine

A Level 1 inspection applies when nothing has changed — same appliance, same fuel, same usage as before, no known problems. The technician examines all *readily accessible* portions of the chimney and flue: the firebox, damper, the flue from below (and above where reachable), the exterior structure, and the basic soundness and clearance of connections. It confirms the flue is clear of blockage and significant deposits. A Level 1 typically rides along with an annual sweeping — it is the routine physical, and for most systems in most years, it is exactly what's called for.



Getting eyes on the whole system is half the job. This is my ladder on a real inspection — three stories of stucco between the ground and the flue we needed to see.

Level 2: When Anything Changes — Including the Owner

A Level 2 inspection is required when conditions change: you changed fuel type or appliance, you relined the flue, there's been an operating malfunction or an external event likely to have caused damage — a chimney fire, a lightning strike, an earthquake, a tree strike — and, critically, **upon sale or transfer of the property**.

Read that again if you are buying a house: the national standard calls for a Level 2 chimney inspection at every real estate

transaction. A general home inspector shining a flashlight up the flue for thirty seconds does not meet that standard — most home inspection reports even say so in their own fine print, disclaiming the chimney interior. A Level 2 includes everything in Level 1 *plus* a video camera scan of the flue interior, plus inspection of accessible attics, crawl spaces, and basements the chimney passes through, with proper clearances checked. It requires no demolition — no tearing into walls — and its cost is trivial next to what it routinely finds in homes changing hands: concealed fire damage, cracked tiles, voided liners, abandoned flues serving live appliances.

If I could put one sentence on a billboard for home buyers in my counties, it would be: *get the Level 2 before you close, because the seller's fireplace worked fine right up until it became your problem.*

Level 3: The Investigation

A Level 3 inspection is the serious one — it includes everything in Levels 1 and 2 plus removal of components or portions of the building where necessary (a chimney crown, an interior chase wall) when a hazard is suspected and cannot be evaluated any other way. Level 3 is uncommon and event-driven — typically after a known chimney fire or structural event. You'll likely never need one; you should simply know the term so the levels can't be shuffled in front of you.



The three NFPA 211 inspection levels. Level 2 — with a camera up the flue — is the one required at every home sale.

What a Real Inspection Leaves Behind

Whatever the level, a legitimate inspection produces a **written report with photos or video stills**: what was examined, what was found, what it means, and what's recommended, in order of urgency. This paper trail is the entire point. It protects you at resale, supports insurance claims after any fire or storm event, and — Chapter 9 is coming — it is the natural enemy of the on-the-spot scare quote, because documented findings can be shown to any second company for a competing bid.

THE ONE-SENTENCE TAKEAWAY

NFPA 211 says every chimney and vent gets inspected every year — Level 1 for routine years, camera-equipped Level 2 whenever anything changes including every home sale, Level 3 for suspected hidden hazards — and every real inspection ends in a written, photographed report.

CHAPTER NINE

The Bait-and-Switch Playbook — and How to Hire a Sweep Who Won't Rip You Off

I told you in the introduction I'd hand you the playbook. Here it is — the whole machine, laid out the way it actually runs. I compete against companies who work this way, I've re-inspected behind them for years, and the pattern is so consistent you could set a script to it. None of what follows means chimney repairs are fake; flues really do fail, liners really are needed, and Chapters 3 through 6 are full of real problems. The scam isn't the existence of repairs. The scam is the *process* — and once you know the process, you're inoculated.

The Playbook, Step by Step

Step 1: The impossible price. A mailer, coupon, or ad offers a chimney sweep for $49–$99. Stop and do the math with me: a legitimate visit means a trained technician, a stocked truck, insurance, drop cloths, HEPA-filtered vacuum equipment, rods and brushes, and an hour-plus on site. Nobody profits at $69. The teaser price is not the product. *You* are the product — the appointment is a sales visit wearing a sweep costume.

Step 2: The discovery. Minutes into the job, the technician emerges gravely concerned. There are "gaps in your liner." "Your smoke chamber is illegal." "I can't let you burn in this." Phone photos are shown — often taken at angles you can't verify, occasionally (documented in news investigations of this industry) not even of your chimney. Every chimney more than a few years old has *something* imperfect to photograph; the playbook inflates a cosmetic finding into a catastrophe.

Step 3: Fear plus a clock. The quote arrives on the spot: thousands, sometimes tens of thousands — full reline, smoke chamber parging, crown rebuild, all "urgent." Then the pressure:

a discount that expires today, a crew that "happens to be free tomorrow," a warning about your family's safety if you delay. Fear plus urgency is the signature of every scam in every industry. Honest findings survive a week of thinking. Dishonest ones can't afford to.

Step 4: The vanishing baseline. And the $69 sweep you originally booked? Either performed in fifteen careless minutes or quietly abandoned — because it was never the point.

The Counter-Moves

Your defense is four sentences long. Memorize them.

1. **"Which NFPA 211 level is this inspection, and is a written report with photos included?"** (Playbook companies flinch at the standard's name; real ones answer instantly.)
2. **"Show me every finding on camera, in my chimney, while I watch."** Modern inspection cameras display live. There is no technical reason you can't see your own flue.
3. **"I don't approve four-figure work on the day it's diagnosed. Leave the report; I'll get a second opinion."** An honest company *expects* this. A finding that's real today is real next Tuesday.
4. **"What's your certification number?"** — which brings us to hiring.

How to Hire the Honest One

Certification. Look for a sweep certified by the **Chimney Safety Institute of America (CSIA)** — the industry's established credential, held by technicians who passed examination on NFPA 211 and chimney physics and who recertify on a cycle. CSIA maintains a public locator to verify a company's status. Membership in the National Chimney Sweep Guild is a good secondary signal. Certification isn't sainthood — but it

screens hard for competence and gives you a body to complain to, which the coupon-mailer companies conspicuously lack.

Insurance and identity. Liability insurance they'll document, a real local address, a track record of reviews spread over years (not a burst of five-star reviews in one month — a known signature of rebranded scam operations, which change names the way other businesses change invoices).

Process. Camera on the truck and used routinely. Drop cloths and dust control inside. Flat, committed pricing for defined services before the visit. Written reports with photos as standard practice, not as an upsell.

Repairs bid like construction. For any big-ticket recommendation — reline, rebuild, parging — get the report, then get two or three competing bids from certified companies, exactly as you would for a roof. Legitimate defects photograph identically for everyone. Prices for fixing them, I promise you, will not be identical.

This is what a legitimate setup looks like: drop cloths protecting the floor, HEPA vacuum, rods staged and ready before anyone touches the flue. Nobody shows up with this equipment — and the time to use it — for a $69 teaser price.

THE ONE-SENTENCE TAKEAWAY

The scam is always the same machine — impossible teaser price, terrifying discovery, expiring quote — and it dies instantly against four counter-moves: name the NFPA 211 level, demand live camera proof, refuse same-day approval of big repairs, and verify CSIA certification before anyone climbs your roof.

CHAPTER TEN

Burn Better: The Habits That Starve Creosote, and Your Year-Round Chimney Plan

Everything so far has been about finding and fixing problems. This final chapter is about *manufacturing fewer of them* — because creosote production is not fate; it is a direct output of how you burn. Two identical fireplaces can produce a tenfold difference in buildup purely from wood and habits. Then we'll close with the full calendar, so this book converts into a system you never have to think hard about again.

Rule One: Burn Seasoned Wood — and Verify It

Freshly cut "green" wood is roughly half water by weight. Burn it and the fire spends its energy boiling water instead of making heat; the result is a cool, smoky, smoldering burn — the exact recipe for creosote from Chapter 3. The EPA's guidance for clean wood burning is specific: burn wood seasoned to a moisture content **below 20 percent**, which typically means splitting and stacking it off the ground, top-covered with sides open, for at least six months — a full year for dense hardwoods like oak.

Don't guess — verify. A wood moisture meter costs about as much as a pizza; split a piece and test the fresh face. Seasoned wood also announces itself: gray and cracked at the ends, light for its size, and it *clinks* rather than thuds. And two absolute nevers: never burn painted, stained, or pressure-treated wood (toxic), and never let household trash, wrapping paper, or cardboard into the fireplace — they flame violently, loft burning fragments up the flue, and are a classic chimney-fire trigger in a creosote-lined chimney.

Rule Two: Burn Hot, Not Smoldering

Creosote condenses out of *cool, slow* smoke. So: build fires that start fast and burn hot — the top-down method (large logs on bottom, kindling on top) produces a hot flue quickly with far less smoke than the log-cabin-and-pray method. Give the fire air; a fireplace damped down to "make the wood last" is a creosote factory. Size fires to burn actively rather than smothering big loads overnight — the overnight smolder is precisely how wood-stove flues glaze. And look at your chimney top occasionally while burning: a hot, clean burn shows thin, nearly transparent smoke; thick gray-white billows mean wet wood or a starved fire, and your flue is collecting the difference.

Rule Three: Respect the Small Physics

Warm the flue before lighting — hold a lit twist of newspaper up past the open damper for a few seconds to reverse a cold column and prevent a room full of startup smoke (keep sleeves, hair, and face out of the opening, and drop the twist into the firebox — not up the flue — the moment it burns close to your hand). Open the damper *fully* every burn. Crack a window near the fireplace if your tight house makes fires sluggish. Use a spark screen or doors as designed. And dispose of ashes like they're live — because they are, sometimes for days: metal can, tight lid, outside, on non-combustible ground, never in a garage, never in a plastic bin. Ash-disposal fires are their own embarrassing statistic, and every one was preventable with a $20 can.

The Year-Round Chimney Plan

Every burn: seasoned wood only; damper fully open; screen in place; no trash in the fire; ashes to the metal can.

Every month of burning season: glance at your smoke (thin and clear?), check the firebox and smoke shelf with a flashlight for debris or tile fragments, and test your smoke and CO alarms.

Every spring (end of burning season): book your sweep and Level 1 inspection now, not in October. Spring booking gets you the best availability, removes the creosote *before* it spends a humid summer smelling up the house, and leaves the whole season to schedule any repairs the inspection finds. This is the single best-kept scheduling secret in the trade — my fall calendar fills with panicked first-cold-snap calls, while spring customers get their pick of dates.

A firebox after a cleaning — walls brushed down, iron grate back in place. The soot on the surround says this fireplace works for a living; the clean flue above it is what lets it keep doing that safely.

Every summer: walk around your chimney with binoculars — crown, cap, flashing, any spalling or shard debris; note animal activity. Have masonry repairs done in warm weather, when mortar and sealants cure properly.

Every fall: confirm the sweep happened (or do it now), test alarms and replace their batteries, check that the damper moves freely, and verify caps are seated after summer storms.

Every real estate transaction: Level 2 inspection, camera included, before closing. No exceptions, including "the seller says it's fine."

After any suspected chimney fire, lightning strike, or chimney-striking event: stop burning; Level 2 before the next fire.

You came into this book with a decorative brick tower you never thought about. You're leaving with a complete mental model of the second most fire-involved system in your house — how it drafts, how it clogs, how it corrodes, how it gets sold against you, and exactly what to do about all of it, on a calendar. Run that calendar once a year and the chimney goes back to being what it should have been all along: a thing you barely have to think about.

THE ONE-SENTENCE TAKEAWAY

Dry wood under 20 percent moisture, hot active fires instead of smolders, a spring sweep, a summer masonry walk-around, and a Level 2 at every home purchase — that calendar is the entire difference between a chimney that serves you for a century and one that makes the news.

APPENDIX A

Chimney Maintenance Log

Photocopy this page or keep it with your home records. A dated log is also real documentation for insurance claims, warranty service, and home resale — a buyer's inspector takes a chimney with a paper trail far more seriously.

Date	Sweep / Inspection (Level)	Findings & Notes	Next Due

Also log: cap installations, crown/flashing repairs, liner work, animal removals, CO alarm test dates and battery changes, and each season's first and last burn.

APPENDIX B

Hiring Checklist — What a Real Sweep and Inspection Includes

Bring this list to any phone call or estimate. A professional will check every box without hesitation — and the boxes a company hesitates on tell you everything.

- ☐ CSIA-certified technician (certification number provided; verifiable on CSIA's locator)
- ☐ Proof of liability insurance offered without argument
- ☐ Flat, committed price for the defined service — sweep, inspection level, or both — before the truck arrives
- ☐ States clearly which NFPA 211 inspection level is being performed
- ☐ Inspects **every** flue in the chimney, including furnace and water-heater flues, not just the fireplace
- ☐ Uses a camera for Level 2 work — and shows me the live feed or footage of my own flue
- ☐ Sweeps with mechanical rod-and-brush agitation plus HEPA-filtered vacuum containment — drop cloths down, house left clean
- ☐ Checks damper operation, smoke shelf, cap condition, crown, and visible flashing
- ☐ Delivers a written report with photos: findings, severity, and recommendations in priority order
- ☐ Prices any recommended repair in writing, valid long enough to get competing bids
- ☐ No expiring same-day discounts, no "I can't let you use this fireplace" theater without documented evidence, no pressure to decide on the spot

☐ Real local address, multi-year review history, and a name they've operated under for more than a season

Glossary

Cap — The metal cover with animal screen installed over a flue opening; keeps out rain, animals, and debris while letting exhaust pass.

Creosote — Combustible residue condensed from wood smoke onto flue walls; progresses from sooty flake (stage one) through hardened tar flakes (stage two) to glazed, brush-proof fuel (stage three).

Crown — The sloped concrete slab sealing the top of a masonry chimney around the flue tiles; the chimney's roof and its most weather-beaten surface.

Damper — The movable metal plate above the firebox (or atop the flue) that opens for burning and closes to stop heat loss when the fireplace is idle.

Draft — The upward pull created by hot, buoyant gas rising in the flue; the engine that moves smoke and exhaust out of the house.

Efflorescence — White mineral deposit left on exterior brick by water evaporating through masonry; a visible confession that the chimney is absorbing water.

Flashing — The layered sheet metal sealing the joint where the chimney passes through the roof; a leading source of roof leaks when failed or tarred over.

Flue — The passage that carries combustion gases; one chimney often contains several flues serving different appliances.

Flue liner — The inner conduit — clay tile, stainless steel, or poured cement — that contains heat and gases and protects the surrounding masonry.

Level 1 / 2 / 3 inspection — The three inspection scopes defined by NFPA 211: routine annual (1); camera-scanned, required upon any change or property sale (2); invasive investigation of suspected concealed hazards (3).

NFPA 211 — The National Fire Protection Association's standard for chimneys, fireplaces, and vents; source of the annual-inspection requirement and the three inspection levels.

Smoke chamber — The sloped funnel between damper and flue where turbulent smoke deposits creosote heavily; smoothing its walls with refractory mortar is called **parging**.

Spalling — Flaking or popping of brick faces caused by absorbed water freezing and expanding; leaves crumbled craters and brick shards around the chimney.

About the Author

Eden Amir is the founder of E Cleaning Duct & Vent Cleaning, a Pennsylvania-licensed air duct, dryer vent, and chimney cleaning company (PA #187935) based in King of Prussia, Pennsylvania. His team has serviced thousands of homes across Chester, Montgomery, Bucks, Berks, Delaware, and Philadelphia counties — sweeping, scoping, capping, and repairing every kind of chimney the region builds, and re-inspecting more than a few behind the companies Chapter 9 warns you about.

He wrote this book for the same reason he wrote its companion, *The Hidden Fire in Your Laundry Room*: the most dangerous hazards in a house are the hidden, preventable ones — and homeowners deserve the industry's honest playbook, including the chapters the industry would rather keep to itself.

Learn more, read the company's guides, or reach the team at:

ecleaning-duct-vent-cleaning.com

(484) 367-5944

Live in Southeastern Pennsylvania?

E Cleaning Duct & Vent Cleaning serves Chester, Montgomery, Bucks, Berks, Delaware, and Philadelphia counties with flat, upfront pricing on chimney sweeps, inspections, air duct and dryer vent cleaning — no teaser rates, no scare tactics, and a camera view of what we found before we leave.

Book your sweep or inspection:

Scan to book online in 60 seconds

ecleaning-duct-vent-cleaning.com

(484) 367-5944